

# SPARE PARTS LIST

MODEL: JEHS-0600-B3-M-3

UNIT PART NUMBER: N04120121

PAGE 1 OF 3

## NOMENCLATURE

**EXAMPLE:**            **A**        **B**        **C**        **D**        **E**        **F**        **G**  
                          JEH        S        0200     B        2        M        1

A	JEH	J & E HALL INTERNATIONAL
B	S	R = RECIPROCATING S = SCROLL
C	0200	APPROXIMATE HP (0200 = 2.0HP)
D	B	UNIT GENERATION
E	2	UNIT SERIES
F	M	M = MEDIUM TEMP L = LOW TEMP
G	1	POWER SUPPLY: 1 = 230V / 1Ph / 50Hz 3 = 400V / 3Ph / 50Hz

# SPARE PARTS LIST

**MODEL: JEHSD-0600-B3-M-3**

**UNIT PART NUMBER: N04120121**

PAGE 2 OF 3

<b>Unit Model</b>	<b>JEHSD-0600-B3-M-3</b>
-------------------	--------------------------

Unit Part Number	N04120121
------------------	-----------

Compressor Model	ZBD45-KQE-TFD-558
------------------	-------------------

## Main Spare Parts

Condenser Coil	N03020112
----------------	-----------

Compressor (Digital)	N01060125
----------------------	-----------

Crankcase Heater	N19030057
------------------	-----------

Liquid Receiver	N39010020
-----------------	-----------

Fusible Plug	N13450028
--------------	-----------

Fan Motor and Blade Assy (incl. Fan Cap)	N11040059
--	-----------

Fan Guard	N11050027
-----------	-----------

Fan Bracket	N13020246
-------------	-----------

Fan Speed Controller (PCB)	N05070023
----------------------------	-----------

High Pressure Switch	N05470032
----------------------	-----------

Low Pressure Switch	N05470033
---------------------	-----------

Filter Drier	N08010196
--------------	-----------

Sight Glass	N27010041
-------------	-----------

HP Transducer	N05120040
---------------	-----------

LP Transducer	N05120041
---------------	-----------

HP Transducer Cable	N09020095
---------------------	-----------

Door Hinge	4x N13660002
------------	--------------

LP Gomax Hose	N13720059
---------------	-----------

Oil Return Gomax Hose	N13720061
-----------------------	-----------

Oil Separator - 5/8"	N26010008
----------------------	-----------

## Valves

Suction Service Valve - 7/8"	N30150169
------------------------------	-----------

Liquid Service Valve - 1/2"	N30150614
-----------------------------	-----------

Check Valve - 1/2"	N30090124
--------------------	-----------

Ball Valve - GBC 12S (Discharge)	N30150453
----------------------------------	-----------

Solenoid Valve - excluding coil	N30010433
---------------------------------	-----------

Solenoid Coil	N30020434
---------------	-----------

# SPARE PARTS LIST

**MODEL: JEHS-0600-B3-M-3**

**UNIT PART NUMBER: N04120121**

PAGE 3 OF 3

<b>Unit Model</b>	<b>JEHS-0600-B3-M-3</b>
Unit Part Number	<b>N04120121</b>
Compressor Model	<b>ZBD45-KQE-TFD-558</b>
<b>Electrical Spares</b>	
Isolator Disconnect Switch	<b>N09140191</b>
Isolator Aux Contact (OA1G10)	<b>N09140192</b>
Isolator Door Handle	<b>N09140193</b>
Motor Starter / Overload - MS132	<b>N09030044</b>
MS132 Aux Contact (HKF1-11)	<b>N09140189</b>
Controller Display (Small)	<b>N05250132</b>
Main Controller	<b>N05250133</b>
Controller Display Cable	<b>N05250146</b>
Temperature Sensor - NTC015WH01 (Suction, Coil & Ambient)	<b>3x N05130114</b>
Temperature Sensor - NTC015HT00 (Compressor Discharge)	<b>N05130113</b>
Fan Capacitor	<b>N09170124</b>
Fuse - 3.15 A	<b>6x N09210082</b>
Fuse - 2.0A	<b>2x N09210308</b>
Fuse Holder	<b>4x N09200010</b>
Relay ABB CR-M230AC4L (Large)	<b>2x N09160140</b>
Relay ABB CR-P230AC1 (Small)	<b>2x N09160143</b>
Relay Base - Large	<b>2x N09160141</b>
Relay Base - Small	<b>2x N09160138</b>
Transformer	<b>N09150069</b>
Rocker Switch	<b>N09240021</b>
Contactor & Aux Contact	<b>N09140260</b>