

# SPARE PARTS LIST

MODEL: JEHS-0800-B4-M-3

UNIT PART NUMBER: N04120122

PAGE 1 OF 3

## NOMENCLATURE

**EXAMPLE:**            **A**        **B**        **C**        **D**        **E**        **F**        **G**  
                          JEH        S        0200     B        2        M        1

A	JEH	J & E HALL INTERNATIONAL
B	S	R = RECIPROCATING S = SCROLL
C	0200	APPROXIMATE HP (0200 = 2.0HP)
D	B	UNIT GENERATION
E	2	UNIT SERIES
F	M	M = MEDIUM TEMP L = LOW TEMP
G	1	POWER SUPPLY: 1 = 230V / 1Ph / 50Hz 3 = 400V / 3Ph / 50Hz

# SPARE PARTS LIST

**MODEL: JEHSD-0800-B4-M-3**

**UNIT PART NUMBER: N04120122**

PAGE 2 OF 3

<b>Unit Model</b>	<b>JEHSD-0800-B4-M-3</b>
-------------------	--------------------------

Unit Part Number	N04120122
------------------	-----------

Compressor Model	ZBD57-KCE-TFD-591
------------------	-------------------

## Main Spare Parts

Condenser Coil - Top	N03020113
----------------------	-----------

Condenser Coil - Bottom	N03020114
-------------------------	-----------

Compressor (Digital)	N01060143
----------------------	-----------

Crankcase Heater	N19030057
------------------	-----------

Liquid Receiver	N39010021
-----------------	-----------

Fusible Plug	N13450036
--------------	-----------

Fan Motor and Blade Assy (incl. Fan Cap)	2x N11040059
--	--------------

Fan Guard	2x N11050027
-----------	--------------

Fan Bracket	2x N13020247
-------------	--------------

Fan Speed Controller (PCB)	N05070023
----------------------------	-----------

High Pressure Switch	N05470032
----------------------	-----------

Low Pressure Switch	N05470033
---------------------	-----------

Filter Drier	N08010196
--------------	-----------

Sight Glass	N27010041
-------------	-----------

HP Transducer	N05120040
---------------	-----------

LP Transducer	N05120041
---------------	-----------

HP Transducer Cable	N09020095
---------------------	-----------

Door Hinge	4x N13660002
------------	--------------

LP Gomax Hose	N13720060
---------------	-----------

Oil Return Gomax Hose	N13720062
-----------------------	-----------

Oil Separator - 7/8"	N26010009
----------------------	-----------

## Valves

Suction Service Valve - 1 1/8"	N30150173
--------------------------------	-----------

Liquid Service Valve - 3/4"	N30150183
-----------------------------	-----------

Check Valve - 3/4"	N30090639
--------------------	-----------

Solenoid Valve - excluding coil	N30010434
---------------------------------	-----------

Solenoid Coil	N30020435
---------------	-----------

# SPARE PARTS LIST

**MODEL: JEHS-D-0800-B4-M-3**

**UNIT PART NUMBER: N04120122**

PAGE 3 OF 3

<b>Unit Model</b>	<b>JEHS-D-0800-B4-M-3</b>
-------------------	---------------------------

Unit Part Number	<b>N04120122</b>
------------------	------------------

Compressor Model	<b>ZBD57-KCE-TFD-591</b>
------------------	--------------------------

## **Electrical Spares**

Isolator Disconnect Switch	<b>N09140191</b>
----------------------------	------------------

Isolator Aux Contact (OA1G10)	<b>N09140192</b>
-------------------------------	------------------

Isolator Door Handle	<b>N09140193</b>
----------------------	------------------

Motor Starter / Overload - MS132	<b>N09030045</b>
----------------------------------	------------------

MS132 Aux Contact (HKF1-11)	<b>N09140189</b>
-----------------------------	------------------

Controller Display (Small)	<b>N05250132</b>
----------------------------	------------------

Main Controller	<b>N05250133</b>
-----------------	------------------

Controller Display Cable	<b>N05250146</b>
--------------------------	------------------

Temperature Sensor - NTC015WH01 (Suction, Coil & Ambient)	<b>3x N05130114</b>
--	---------------------

Temperature Sensor - NTC015HT00 (Compressor Discharge)	<b>N05130113</b>
---	------------------

Fan Capacitor	<b>2x N09170124</b>
---------------	---------------------

Fuse - 3.15 A	<b>6x N09210082</b>
---------------	---------------------

Fuse - 2.0A	<b>2x N09210308</b>
-------------	---------------------

Fuse Holder	<b>4x N09200010</b>
-------------	---------------------

Relay ABB CR-M230AC4L (Large)	<b>2x N09160140</b>
-------------------------------	---------------------

Relay ABB CR-P230AC1 (Small)	<b>2x N09160143</b>
------------------------------	---------------------

Relay Base - Large	<b>2x N09160141</b>
--------------------	---------------------

Relay Base - Small	<b>2x N09160138</b>
--------------------	---------------------

Transformer	<b>N09150069</b>
-------------	------------------

Rocker Switch	<b>N09240021</b>
---------------	------------------

Contactor	<b>N09140313</b>
-----------	------------------