

SPARE PARTS LIST

MODEL: JEHSDT-1200-B5-M-3

UNIT PART NUMBER: N04120128

PAGE 1 OF 4

NOMENCLATURE

EXAMPLE: **A** **B** **C** **D** **E** **F** **G**
 JEH S 0200 B 2 M 1

A	JEH	J & E HALL INTERNATIONAL
B	S	R = RECIPROCATING S = SCROLL
C	0200	APPROXIMATE HP (0200 = 2.0HP)
D	B	UNIT GENERATION
E	2	UNIT SERIES
F	M	M = MEDIUM TEMP L = LOW TEMP
G	1	POWER SUPPLY: 1 = 230V / 1Ph / 50Hz 3 = 400V / 3Ph / 50Hz

SPARE PARTS LIST

MODEL: JEHSDT-1200-B5-M-3

UNIT PART NUMBER: N04120128

PAGE 2 OF 4

Unit Model

JEHSDT-1200-B5-M-3

Unit Part Number

N04120128

Compressor Model

**ZBD45-KQE-TFD-558
+ ZB45-KQE-TFD-558**

Main Spare Parts

Condenser Coil

2x N03020219

Compressor (Digital)

N01060125

Compressor (Standard)

N01060076

Crankcase Heater

2x N19030057

Oil Management System - OM3

2x N05110037

Liquid Receiver

N39010015

Fan Motor and Blade Assy (incl. Fan Cap)

2x N11040059

Fan Guard

2x N11050027

Fan Bracket

2x N13020248

Fan Speed Controller (PCB)

N05070023

High Pressure Switch

2x N05470032

Low Pressure Switch

N05470105

Filter Drier

N08010231

Sight Glass

N27010067

HP Transducer

N05120040

LP Transducer

N05120041

HP Transducer Cable

N09020095

Door Hinge

8x N13660002

LP Gomax Hose

N13720063

Oil Return Gomax Hose

N13720064

Oil Separator / Reservoir

N26010073

SPARE PARTS LIST

MODEL: JEHSDT-1200-B5-M-3

UNIT PART NUMBER: N04120128

PAGE 3 OF 4

Unit Model

JEHSDT-1200-B5-M-3

Unit Part Number

N04120128

Compressor Model

**ZBD45-KQE-TFD-558
+ ZB45-KQE-TFD-558**

Valves

Pressure Relief Valve

N30070163

Suction Service Valve - 1 3/8"

N31050235

Liquid Service Valve - 3/4"

N30150183

Check Valve - 1/2"

2x N30090124

Check Valve - 7/8"

N30090125

Ball Valve - GBC 22S (Suction)

2x N30150416

Ball Valve - GBC 12S (Discharge)

2x N30150418

Ball Valve - GBC 18S (Discharge/Liquid)

N30150415

Solenoid Valve - excluding coil

N30010433

Solenoid Coil

N30020434

Electrical Spares

Isolator Disconnect Switch

N09030048

Isolator Aux Contact (OA1G10)

N09140192

Isolator Door Handle

N09140223

Motor Starter / Overload - MS132

2x N09030044

MS132 Aux Contact (HKF1-11)

N09140189

Phase Protection Device

N09190013

Controller Display (Large)

N05200023

Main Controller

N05460031

Controller Display Cable

N05250146

Temperature Sensor - NTC015WH01
(Suction, Coil & Ambient)

3x N05130114

Temperature Sensor - NTC015HT00
(Compressor Discharge)

2x N05130113

SPARE PARTS LIST

MODEL: JEHSDT-1200-B5-M-3

UNIT PART NUMBER: N04120128

PAGE 4 OF 4

Unit Model

JEHSDT-1200-B5-M-3

Unit Part Number

N04120128

Compressor Model

**ZBD45-KQE-TFD-558
+ ZB45-KQE-TFD-558**

Electrical Spares continued

Fan Capacitor

2x N09170124

Fuse - 3.15 A

8x N09210082

Fuse Holder

4x N09200010

Relay ABB CR-M230AC4L (Large)

2x N09160140

Relay ABB CR-P230AC1 (Small)

2x N09160143

Relay Base - Large

2x N09160141

Relay Base - Small

2x N09160138

Transformer

N09150069

Rocker Switch

N09240021

Contactors

2x N09140188

Red Light (Alarm)

N09100015

Yellow Light (Compressor Run)

N09100016

Green Light (Mains Power)

N09100017

Blue Light (Bypass)

N09100018