

SPARE PARTS LIST

MODEL: JEHSDT-1200-B5-M-3

UNIT PART NUMBER: N04120128

PAGE 1 OF 4

NOMENCLATURE

EXAMPLE: **A** **B** **C** **D** **E** **F** **G**
 JEH S 0200 B 2 M 1

A	JEH	J & E HALL INTERNATIONAL
B	S	R = RECIPROCATING S = SCROLL
C	0200	APPROXIMATE HP (0200 = 2.0HP)
D	B	UNIT GENERATION
E	2	UNIT SERIES
F	M	M = MEDIUM TEMP L = LOW TEMP
G	1	POWER SUPPLY: 1 = 230V / 1Ph / 50Hz 3 = 400V / 3Ph / 50Hz

SPARE PARTS LIST

MODEL: JEHSDT-1200-B5-M-3

UNIT PART NUMBER: N04120128

PAGE 2 OF 4

Unit Model

JEHSDT-1200-B5-M-3

Unit Part Number

N04120128

Compressor Model

**ZBD45-KQE-TFD-558
+ ZB45-KQE-TFD-558**

Main Spare Parts

Condenser Coil

2x N03020219

Compressor (Digital)

N01060125

Compressor (Standard)

N01060076

Crankcase Heater

2x N19030057

Oil Management System - OM3

2x N05110037

Liquid Receiver

N39010015

Fan Motor and Blade Assy (incl. Fan Cap)

2x N11040059

Fan Guard

2x N11050027

Fan Bracket

2x N13020248

Fan Speed Controller (PCB)

N05070023

High Pressure Switch

2x N05470032

Low Pressure Switch

N05470105

Filter Drier

N08010231

Sight Glass

N27010067

HP Transducer

N05120040

LP Transducer - before October 2020

N05120041

LP Transducer - from October 2020

N05120303

HP Transducer Cable

N09020095

LP & HP Transducer Cable - from October 2020

2 x N09020334

NB N09020334 is backwards compatible with N09020095

Door Hinge

8x N13660002

LP Gomax Hose

N13720063

Oil Return Gomax Hose

N13720064

Oil Separator / Reservoir

N26010073

SPARE PARTS LIST

MODEL: JEHSDT-1200-B5-M-3

UNIT PART NUMBER: N04120128

PAGE 3 OF 4

Unit Model

JEHSDT-1200-B5-M-3

Unit Part Number

N04120128

Compressor Model

**ZBD45-KQE-TFD-558
+ ZB45-KQE-TFD-558**

Valves

Pressure Relief Valve

N30070163

Suction Service Valve - 1 3/8"

N31050235

Liquid Service Valve - 3/4"

N30150183

Check Valve - 1/2"

2x N30090124

Check Valve - 7/8"

N30090125

Ball Valve - GBC 22S (Suction)

2x N30150416

Ball Valve - GBC 12S (Discharge)

2x N30150418

Ball Valve - GBC 18S (Discharge/Liquid)

N30150415

Solenoid Valve - excluding coil

N30010433

Solenoid Coil

N30020434

Electrical Spares

Isolator Disconnect Switch

N09030048

Isolator Aux Contact (OA1G10)

N09140192

Isolator Door Handle

N09140223

Motor Starter / Overload - MS132

2x N09030044

MS132 Aux Contact (HKF1-11)

N09140189

Phase Protection Device

N09190013

Controller Display (Large)

N05200023

Main Controller - before Oct 2020

N05460031

Main Controller - from Oct 2020

N05250195

Controller Display Cable

N05250146

Temperature Sensor - NTC015WH01

3x N05130114

(Suction, Coil & Ambient)

Temperature Sensor - NTC015HT00

2x N05130113

(Compressor Discharge)

SPARE PARTS LIST

MODEL: JEHSDT-1200-B5-M-3

UNIT PART NUMBER: N04120128

PAGE 4 OF 4

Unit Model

JEHSDT-1200-B5-M-3

Unit Part Number

N04120128

Compressor Model

**ZBD45-KQE-TFD-558
+ ZB45-KQE-TFD-558**

Electrical Spares continued

Fan Capacitor	2x N09170124
Fuse - 3.15 A	8x N09210082
Fuse Holder	4x N09200010
Relay ABB CR-M230AC4L (Large) - before Jan2021	2x N09160140
Schneider Relay RXM4AB2P7 (Large) - from Jan 2021	2x N09160469
Relay ABB CR-P230AC1 (Small)	2x N09160143
Relay Base - Large - before Jan 2021	2x N09160141
Relay Base - Large - from Jan 2021	2x N09160470
Relay Holder - Large - from Jan 2021	2 x N09160471
Relay Base - Small	2x N09160138
Transformer	N09150069
Rocker Switch	N09240021
Contactors	2x N09140188
Red Light (Alarm)	N09100015
Yellow Light (Compressor Run)	N09100016
Green Light (Mains Power)	N09100017
Blue Light (Bypass)	N09100018