

# SPARE PARTS LIST

MODEL: JEHSDT-1600-B6-M-3

UNIT PART NUMBER: N04120134

PAGE 1 OF 4

## NOMENCLATURE

**EXAMPLE:**            **A**      **B**      **C**      **D**      **E**      **F**      **G**  
                         JEH      S      0200      B      2      M      1

A	JEH	J & E HALL INTERNATIONAL
B	S	R = RECIPROCATING S = SCROLL
C	0200	APPROXIMATE HP (0200 = 2.0HP)
D	B	UNIT GENERATION
E	2	UNIT SERIES
F	M	M = MEDIUM TEMP L = LOW TEMP
G	1	POWER SUPPLY: 1 = 230V / 1Ph / 50Hz 3 = 400V / 3Ph / 50Hz

# SPARE PARTS LIST

**MODEL: JEHSDT-1600-B6-M-3**

**UNIT PART NUMBER: N04120134**

PAGE 2 OF 4

## Unit Model

**JEHSDT-1600-B6-M-3**

Unit Part Number

**N04120134**

Compressor Model

**ZBD57-KCE-TFD-591  
+ ZB57-KCE-TFD-591**

## Main Spare Parts

Condenser Coil

**2x N03020221**

Compressor (Digital)

**N01060143**

Compressor (Standard)

**N01060159**

Crankcase Heater

**2x N19030057**

Oil Management System - OM3

**2x N05110037**

Liquid Receiver

**N39010015**

Fan Motor and Blade Assy (incl. Fan Cap)

**2x N11040059**

Fan Guard

**2x N11050027**

Fan Bracket

**2x N13440212**

Fan Speed Controller (PCB)

**N05070023**

High Pressure Switch

**2x N05470032**

Low Pressure Switch

**N05470105**

Filter Drier

**N08010231**

Sight Glass

**N27010067**

HP Transducer

**N05120040**

LP Transducer

**N05120041**

HP Transducer Cable

**N09020095**

Door Hinge

**8x N13660002**

LP Gomax Hose

**N13720067**

Oil Return Gomax Hose

**N13720068**

Oil Separator / Reservoir

**N26010073**

# SPARE PARTS LIST

**MODEL: JEHSDT-1600-B6-M-3**

**UNIT PART NUMBER: N04120134**

PAGE 3 OF 4

## Unit Model

**JEHSDT-1600-B6-M-3**

Unit Part Number

**N04120134**

Compressor Model

**ZBD57-KCE-TFD-591  
+ ZB57-KCE-TFD-591**

## Valves

Pressure Relief Valve

**N30070163**

Suction Service Valve - 1 3/8"

**N31050235**

Liquid Service Valve - 3/4"

**N30150183**

Check Valve - 3/4"

**2x N30090654**

Check Valve - 7/8"

**N30090655**

Ball Valve - GBC 22S (Suction)

**2x N30150416**

Ball Valve - GBC 18S (Discharge/Liquid)

**3x N30150415**

Solenoid Valve - excluding coil

**N30010434**

Solenoid Coil

**N30020435**

## Electrical Spares

Isolator Disconnect Switch

**N09030048**

Isolator Aux Contact (OA1G10)

**N09140192**

Isolator Door Handle

**N09140223**

Motor Starter / Overload - MS132

**2x N09030044**

MS132 Aux Contact (HKF1-11)

**N09140189**

Phase Protection Device

**N09190013**

Controller Display (Large)

**N05200023**

Main Controller

**N05460031**

Controller Display Cable

**N05250146**

Temperature Sensor - NTC015WH01  
(Suction, Coil & Ambient)

**3x N05130114**

Temperature Sensor - NTC015HT00  
(Compressor Discharge)

**2x N05130113**

# SPARE PARTS LIST

**MODEL: JEHSDT-1600-B6-M-3**

**UNIT PART NUMBER: N04120134**

PAGE 4 OF 4

## Unit Model

**JEHSDT-1600-B6-M-3**

Unit Part Number

**N04120134**

Compressor Model

**ZBD57-KCE-TFD-591  
+ ZB57-KCE-TFD-591**

## Electrical Spares continued

Fan Capacitor

**2x N09170124**

Fuse - 3.15 A

**8x N09210082**

Fuse Holder

**4x N09200010**

Relay ABB CR-M230AC4L (Large)

**2x N09160140**

Relay ABB CR-P230AC1 (Small)

**2x N09160143**

Relay Base - Large

**2x N09160141**

Relay Base - Small

**2x N09160138**

Transformer

**N09150069**

Rocker Switch

**N09240021**

Contactors

**2x N09140188**

Red Light (Alarm)

**N09100015**

Yellow Light (Compressor Run)

**N09100016**

Green Light (Mains Power)

**N09100017**

Blue Light (Bypass)

**N09100018**